

VREC-Z820DC Firmware Update Procedure

STEP 1a : FORMAT THE SD CARD Using PC

1. Insert the SD card into the slot of a PC or desktop computer.
2. In File Explorer, right click the SD Card drive and select "Format"
3. Click "Start" and then click "OK" when prompted.
4. Once Format is completed, proceed to **STEP 2**.

STEP 1b : FORMAT THE SD CARD using another VREC model

1. Insert the SD card into the slot of a working VREC unit.
2. A prompt to format the card will appear on the VREC screen.
3. Click the "Format" button on the VREC unit.
4. Remove the SD card from the VREC unit once format completes and insert to the PC.
5. Proceed to STEP 2.

STEP 2 : UPDATING THE FIRMWARE

1. Extract the firmware file from the ZIP file.
2. Copy the file [FW_1015.bin](#) to the root directory of the SD card. (No Folders / No other files)
3. Remove power of VREC unit and insert the SD card into the designated slot.
4. Apply power to the VREC unit.
5. The VREC unit screen will display "Updating Firmware ..."
6. Once the upgrade is successful, VREC will reboot, and will ask for set the language & time & LED will be green post select these mentioned settings.
7. You can verify the updated version number from the VREC UI or mobile application's Settings page.