Pioneer MVH-85UB Update Procedure

Preparation

1. Download the firmware from Pioneer website (https://pioneer-mea.com/en/software-and-firmware/) and unzip it.

2. Copy the unzipped files (MVH-0xUB.MP3 ; updata.cdp) on to a blank USB memory. No folders / no other files.

Update Procedure

1. Turn On the power of the unit.

2. Connect the USB to the USB port of the unit. The USB source is automatically selected and recognized.

3. After the mp3 file on the USB is played, press the [DISP] key for 3 times, the model name [MVH-xxxx] is displayed.

4. Press the [DISP] and [2] key at the same time, "UPDATE MCU" is displayed and the update starts automatically.

5. After in around 20 seconds, unit restarts. The update is finished.

6. Turn off the power (BUP and Acc), unplug the USB.

7. Referring to "Version Confirmation" method, confirm the Version becomes the current one.

PIONEER GULF FZE
P.O. Box 61226, Jebel Ali, Dubai, United Arab Emirates
TEL: (971) 4 8815756 FAX: (971) 4 8816414
Formed Pursuant to Law No. 9 of 1992
With Limited Liability

بايونير جلف م م ح ص.ب : ٦١٢٢٦ ، جبل علي ، دبي - إ.ع.م.
تليفون: ٨٨١٥٧٥٦-٤(٩٧١) ، فاكس: ٨٨١٦٤١٤-٤(٩٧١)
ذات مسئولية محدودة تأسست بموجب
القانون رقم : ٩ لسنة ١٩٩٢